

PRO3200E Quick Reference Guide

High Performance access control for installations of any size

PRO3200E ENCLOSURES



PRO22ENC1
Wall Mount up to Rack Mount
up to PS 9 boards + PS



PRO22ENC2
Rack Mount up to
9 brds + PS 9 boards + PS



BW-PRO32SMBO
Surface Mount Enclosure
for PRO32R2



PRO22ENC3
Wall Mount up to 2 boards



PRO22ENC4
Enclosure for PRO22R1



BW-PRO32FMBO
Flush Mount Enclosure
for PRO32R2



PRO22ENC5
Rack only, no enclosure



BW-PRO32NEXA
Nexwatch Enclosure adapter
backplane for PRO3200E retrofits



BW-PRO32BOX
PRO3200E Enclosure
for up to 20 boards

PRO3200E BOARDS



PRO321C
Intelligent controller supports
32 downstream boards



PRO22MX8
8 channel RS485 Multiplexer



PRO32R2
2 Reader Board



PRO32IN
16 Input Module



PRO32OUT
16 Output Module



PRO22R1
1 Reader Board



PW6K1ICE
Mercury Intelligent
PoE Controller (EP1501)

PRO3200E ACCESSORIES



PRO32E1PS
PS for ENC1 or ENC2



PRO22BAT1
12V, 7AH sealed
lead acid battery



PRO22DCC
Daisy Chain Cable for
ENC1 or ENC2



S-4
Suppressor kit used per relay
controlling a lock/strike

SUPPORTED READER FORMATS

Supports 5/12VDC
at 50mA, clock/data or
data0/data1

ORDERING	
PRO3200E CONTROLLERS	
PRO32IC	PRO3200E Intelligent Controller
PRO22R1	PRO3200E Single Reader Module
PRO32R2	PRO3200E Dual Reader Module
PRO32OUT	PRO3200E 16 Relay Output Module
PRO32IN	PRO3200E 16 Alarm Input Module
AUTHENTIC MERCURY CONTROLLERS	
PW6K1ICE	Mercury Intelligent PoE Controller (EP1501)
PRO-SERIES ENCLOSURES	
PRO22ENC1	(Wall-mount) Capacity: 9 modules. Power supply and battery not included
PRO22ENC2	(19" Rack-mount) Capacity: 9 modules. Power supply and battery not included
PRO22ENC3	(Tile-mount) Capacity: 2 modules. Power supply and battery included
PRO22ENC4	(Tile-mount) Capacity: 1 module (PRO22R1 only). Power supply and battery included
PRO22ENC5	(Cage only for custom enclosures) Capacity: 9 modules. Power supply and battery not included
PRO3200E ENCLOSURES (AVAILABLE ONLY FROM ADI)	
BW-PRO32SMBO	Surface Mount Enclosure for PRO32R2 (or equivalent footprint)
BW-PRO32FMBO	Flush Mount Enclosure for PRO32R2 (or equivalent footprint)
BW-PRO32NEXA	Nexwatch Enclosure adapter backplane for PRO3200E retrofits
BW-PRO32BOX	PRO3200E Enclosure for up to 20 boards (stacked tile fashion)
OPTIONAL ACCESSORIES	
PRO22DCC	Daisy Chain cable required for PRO22ENC1, PRO22ENC2 and PRO22ENC5
PRO32E1PS	4 A rack-mounted power supply with battery backup required for PRO22ENC1, PRO22ENC2 and PRO22ENC5
PRO22MX8	8 Channel RS485 Multiplexer
NETWORK KITS	
PRO32E1EN	Includes: PRO22ENC1, PRO32IC, PRO32E1PS, PRO22BAT1 and PRO22DCC
PRO32E2EN	Includes: PRO22ENC2, PRO32IC, PRO32E1PS, PRO22BAT1 and PRO22DCC
PRO32E1D2	Includes: PRO22ENC1, PRO32IC, PRO32R2, PRO32E1PS, PRO22BAT1, PRO22DCC and 2 x S-4
PRO32E1D4	Includes: PRO22ENC1, PRO32IC, 2 x PRO32R2, PRO32E1PS, PRO22BAT1, PRO22DCC and 4 x S-4
PRO32E1D8	Includes: PRO22ENC1, PRO32IC, 4 x PRO32R2, PRO32E1PS, PRO22BAT1, PRO22DCC and 8 x S-4

Find Out More

For more information please call
1.800.345.6770 or visit
buildingsolutions.honeywell.com

Honeywell Building Solutions

1985 Douglas Drive North
Golden Valley, MN 55422
1.800.345.6770
www.honeywell.com



All specifications are subject
to change without notice

SL-53-2548 | 09/19
© 2019 Honeywell International Inc.

**THE
FUTURE
IS
WHAT
WE
MAKE IT**

Honeywell